



Drying Time

During the film installation, Solas will remove as much of the installation fluid as possible, but a small amount will still remain. This may result in small water bubbles appearing and/ or a slightly cloudy view.

This is normal and should be expected. Do not pierce the water bubbles during this drying period. This damage to the window film will not be covered by the warranty. The water bubble and cloudy view will disappear over time.

Film type and climate conditions will determine the drying time you experience. Warm weather and direct sunlight will shorten the drying time, while cooler climates, cloudy conditions and thicker films may prolong it.

Drying may vary from a few days to 6 months. The trapped moisture will dry out completely.

Cleaning

Do not clean the window film for 30 days after it is installed. This helps the installation fluid to dry which secures the special mounting adhesive to the glass.

The best cleaning method is to use ½ ounce of liquid detergent mixed with about 1 quart of pure de-mineralized water. We do not recommend degreasing agents or detergents containing alcohol, acid or ammonia.

Always use clean, soft materials to clean and dry the coated surfaces. A soft cloth or sponge is recommended for washing the window, followed by another soft cloth or rubber squeegee to dry the film.

To avoid scratching the film, do not use bristle brushes or abrasive sponges. These materials can cause fine scratches on the surface of the window film and cause the polished layer of the film to deteriorate over time.

If you have any questions, do not hesitate to contact us:

Solas Window Tint
2038 Huntwood Dr
Gambrills, MD 21054

410-451-8050